

Smith Chart of 0.01uH Inductor (Measurement with shortened wire)  
All components are sampled from 1 MHz to 501 MHz

- Air-Core
- T-30-0(50-300MHz)
- T-30-2(1-30MHz)
- T-30-6(2-50MHz)
- T-30-7(5-35MHz)
- T-30-10(10-100MHz)
- T-30-12(20-200MHz)

